

# Complex Numbers Review

Reference: Mary L. Boas, *Mathematical Methods in the Physical Sciences*  
Chapter 2 & 14  
George Arfken, *Mathematical Methods for Physicists*  
Chapter 6

The real numbers (denoted  $\mathbb{R}$ ) are incomplete in the sense that standard operations applied to some real numbers do not yield a real result (e.g., square root:  $\sqrt{-1}$ ). It is surprisingly easy to enlarge the set of real numbers producing a set of numbers that *is* closed under standard operations: one simply needs to include  $\sqrt{-1}$  (and linear combinations of it). Thus this enlarged field of numbers, called the *complex numbers* (denoted  $\mathbb{C}$ ), consists of numbers of the form:  $z = a + b\sqrt{-1}$  where  $a$  and  $b$  are real numbers. There are lots of notations for these numbers. In mathematics,  $\sqrt{-1}$  is called  $i$  (so  $z = a + bi$ ), whereas in electrical engineering  $i$  is frequently used for current, so  $\sqrt{-1}$  is called  $j$  (so  $z = a + bj$ ). In *Mathematica* complex numbers are constructed using  $\mathbf{I}$  for  $i$ . Since complex numbers require two real numbers to specify them they can also be represented as an ordered pair:  $z = (a, b)$ . In any case  $a$  is called the real part of  $z$ :  $a = \text{Re}(z)$  and  $b$  is called the imaginary part of  $z$ :  $b = \text{Im}(z)$ . Note that the imaginary part of any complex number is real and the imaginary part of any real number is zero. Finally there is a polar notation which reports the radius (a.k.a. absolute value or magnitude) and angle (a.k.a. phase or argument) of the complex number in the form:  $r\angle\theta$ . The polar notation can be converted to an algebraic expression because of a surprising relationship between the exponential function and the trigonometric functions:

$$e^{j\theta} = \cos \theta + j \sin \theta$$

Thus there is a simple formula for the complex number  $z_1$  in terms of its magnitude and angle:

$$\begin{aligned} |z_1| &\equiv \sqrt{a^2 + b^2} = r \\ a &= r \cos \theta = |z_1| \cos \theta \\ b &= r \sin \theta = |z_1| \sin \theta \\ z_1 &= a + bj = |z_1|(\cos \theta + j \sin \theta) = |z_1|e^{j\theta} \end{aligned}$$

For example, we have the following notations for the complex number  $1 + i$ :

$$1 + i = 1 + j = 1 + \mathbf{I} = (1, 1) = \sqrt{2}\angle 45^\circ = \sqrt{2}e^{j\pi/4}$$

Since complex numbers are closed under the standard operations, we can define things which previously made no sense:  $\log(-1)$ ,  $\arccos(2)$ ,  $(-1)^\pi$ ,  $\sin(i)$ ,  $\dots$ . The complex numbers are large enough to define every function value you might want. Note that addition, subtraction, multiplication, and division of complex numbers proceeds as usual, just using the symbol for  $\sqrt{-1}$  (let's use  $j$ ):

$$z_1 = a + bj \quad z_2 = c + dj$$




Figure 1: Complex numbers can be displayed on the complex plane. A complex number  $z = a + bi$  may be displayed as an ordered pair:  $(a, b)$ , with the “real axis” the usual  $x$ -axis and the “imaginary axis” the usual  $y$ -axis. Complex numbers are also often displayed as vectors pointing from the origin to  $(a, b)$ . The angle  $\theta$  can be found from the usual trigonometric functions;  $|z| = r$  is the length of the vector.

$$\begin{aligned}
 z_1 + z_2 &= (a + bj) + (c + dj) = (a + c) + (b + d)j \\
 z_1 - z_2 &= (a + bj) - (c + dj) = (a - c) + (b - d)j \\
 z_1 \times z_2 &= (a + bj) \times (c + dj) = ac + adj + bcj + bdj^2 = (ac - bd) + (ad + bc)j \\
 \frac{1}{z_1} &= \frac{1}{a + bj} = \frac{1}{a + bj} \times \frac{a - bj}{a - bj} = \frac{a - bj}{a^2 + b^2} = \frac{a}{a^2 + b^2} + \frac{-b}{a^2 + b^2} j
 \end{aligned}$$

Note in calculating  $1/z_1$  we made use of the complex number  $a - bj$ ;  $a - bj$  is called the *complex conjugate* of  $z_1$  and it is denoted by  $z_1^*$  or sometimes  $\bar{z}_1$ . See that  $zz^* = |z|^2$ . Note that, in terms of the ordered pair representation of  $\mathbb{C}$ , complex number addition and subtraction looks just like component-by-component vector addition:

$$(a, b) + (c, d) = (a + c, b + d)$$

Thus there is a tendency to denote complex numbers as vectors rather than points in the complex plane.

While the closure property of the complex numbers is dear to the hearts of mathematicians, the main use of complex numbers in science is to represent sinusoidally varying quantities in a simple way. For example, you may remember that the superposition of sinusoidal quantities is itself sinusoidal, but with a new amplitude and phase. For example, in a series  $RC$  circuit the voltage across the resistor might be given by  $A \cos \omega t$  whereas the voltage across the capacitor might be given by  $B \sin \omega t$ , and the voltage across the combination (according to Kirchhoff) is the sum:

$$\begin{aligned}
 V_R(t) + V_C(t) &= A \cos \omega t + B \sin \omega t \quad \text{where: } A, B \in \mathbb{R} \\
 &= \sqrt{A^2 + B^2} \left( \frac{A}{\sqrt{A^2 + B^2}} \cos \omega t + \frac{B}{\sqrt{A^2 + B^2}} \sin \omega t \right) \\
 &= \sqrt{A^2 + B^2} (\cos \delta \cos \omega t + \sin \delta \sin \omega t) \quad \text{where: } \cos \delta = \frac{A}{\sqrt{A^2 + B^2}} \\
 &= \sqrt{A^2 + B^2} \cos(\omega t - \delta)
 \end{aligned}$$

Yuck! That’s a lot of work just to add two sinusoidal waves; we seek a simpler method (which might not seem overly simple at first glance). Note that  $V_R$  can be written as




Figure 2: The complex conjugate is obtained by reflecting the vector in the real axis. Complex number addition works just like vector addition.

$\text{Re}(Ae^{j\omega t})$  and  $V_C$  can be written as  $\text{Re}(-jBe^{j\omega t})$  so:

$$V_R(t) + V_C(t) = \text{Re}((A - jB)e^{j\omega t})$$

Now using the polar form of the complex number  $A - jB$ :

$$A - jB = \sqrt{A^2 + B^2} e^{-j\delta} \quad \text{where: } \tan \delta = B/A$$

we have:

$$\begin{aligned} V_R(t) + V_C(t) &= \text{Re}((A - jB)e^{j\omega t}) \\ &= \text{Re}\left(\sqrt{A^2 + B^2} e^{-j\delta} e^{j\omega t}\right) \\ &= \sqrt{A^2 + B^2} \text{Re}\left(e^{j(\omega t - \delta)}\right) \\ &= \sqrt{A^2 + B^2} \cos(\omega t - \delta) \end{aligned}$$

## Differential Equations and $e^{i\omega t}$

Complex exponentials provide a fast and easy solution for many differential equations. Consider the damped harmonic oscillator:

$$F_{\text{net}} = -kx - bv = ma \quad (1)$$

or:

$$0 = \frac{d^2x}{dt^2} + \frac{b}{m} \frac{dx}{dt} + \frac{k}{m} x \quad (2)$$

Seeking a more compact notation, we redefine the constants in this expression:

$$\frac{b}{m} \equiv 2\beta \quad \frac{k}{m} \equiv \omega_0^2 \quad (3)$$

So:

$$\frac{d^2x}{dt^2} + 2\beta \frac{dx}{dt} + \omega_0^2 x = 0 \quad (4)$$

If we guess a solution of the form:  $x = Ae^{rt}$ , we find:

$$[r^2 + 2\beta r + \omega_0^2] Ae^{rt} = 0 \quad (5)$$

Since  $e^{rt}$  is never zero,  $r$  must be a root of the quadratic equation in square brackets.

$$r = \frac{-2\beta \pm \sqrt{4\beta^2 - 4\omega_0^2}}{2} = \beta \pm i\sqrt{\omega_0^2 - \beta^2} \quad (6)$$

where we have assumed  $\omega_0 > \beta$ . Defining the free oscillation frequency  $\omega_1 = \sqrt{\omega_0^2 - \beta^2}$ , we have a solution:

$$x = \text{Re} [A e^{-\beta t} e^{i\omega_1 t}] = |A| e^{-\beta t} \cos(\omega_1 t + \phi) \quad (7)$$

In the driven, damped harmonic oscillator, we have a driving force:  $F_0 \cos \omega t$  in addition to the other forces:

$$F_{\text{net}} = F_0 \cos \omega t - kx - bv = ma \quad (8)$$

Defining  $A_0 = F_0/m$  yields the differential equation:

$$\frac{d^2 x}{dt^2} + 2\beta \frac{dx}{dt} + \omega_0^2 x = A_0 \cos(\omega t) \quad (9)$$

If we seek a solution that oscillates at the driving frequency:  $x = \text{Re} [Ae^{i\omega t}]$ , our differential equation becomes:

$$[-\omega^2 + 2\beta i\omega + \omega_0^2] Ae^{i\omega t} = A_0 e^{i\omega t} \quad (10)$$

So:

$$A = \frac{A_0}{(\omega_0^2 - \omega^2) + 2\beta i\omega} \quad (11)$$

From which we can extract the amplitude and phase of the oscillation, for example:

$$|A| = \frac{A_0}{\sqrt{(\omega_0^2 - \omega^2)^2 + 4\beta^2 \omega^2}} \quad (12)$$

One can show that the amplitude is largest for

$$\omega_2 = \sqrt{\omega_0^2 - 2\beta^2} \quad (13)$$

Finally it is customary to describe driven oscillators in terms of a dimensionless *quality factor*,  $Q$ ,

$$Q = \frac{\omega_0}{2\beta} \quad (14)$$

If we then let  $x$  be the dimensionless frequency ratio  $\omega/\omega_0$ , we can write the oscillation amplitude in a particularly simple form:

$$|A| = \frac{A_0/\omega_0^2}{\sqrt{(1-x^2)^2 + x^2/Q^2}} \quad (15)$$

Notice that the case of small damping (small  $\beta$ ) corresponds to large  $Q$ .





Figure 3: Resonance: the amplitude factor:  $\frac{1}{\sqrt{(1-x^2)^2+x^2/Q^2}}$  is plotted as a function of the dimensionless frequency ratio:  $x = \omega/\omega_0$  for the case  $Q = 20$ . Clearly the largest amplitude occurs when  $x \approx 1$ , i.e.,  $\omega \approx \omega_0$

## Homework

1. Prove that when you multiply complex numbers  $z_1$  and  $z_2$ , the magnitude of the result is the product of the magnitudes of  $z_1$  and  $z_2$ , and the phase of the product is the sum of the phases of  $z_1$  and  $z_2$ .



2. Express the following in the  $r\angle\theta$  format (I bet your calculator can do this automatically):

(a)  $\frac{1}{1+i}$       (b)  $\frac{3+i}{1+3i}$       (c)  $25e^{2i}$       (d)  $(1/(1+i))^*$       (e)  $\left| \frac{1}{(1+i)} \right|$

3. Find the following in  $(a, b)$  format (I bet your calculator can do this automatically):

(a)  $\frac{3i-7}{i+4}$       (b)  $(.64 + .77i)^4$       (c)  $\sqrt{3+4i}$       (d)  $25e^{2i}$       (e)  $\ln(-1)$

4. Using the Euler relation:  $e^{i\theta} = \cos \theta + i \sin \theta$  show that:

$$\frac{d}{dt} e^{i\omega t} = i\omega e^{i\omega t}$$

where  $\omega$  is real and constant.

5. Show:  $\forall z \in \mathbb{C}: |z/\bar{z}| = 1$ , so  $z/\bar{z} = e^{i\theta}$  (for some  $\theta \in \mathbb{R}$ ). What is the relationship between the phase of  $z$  and  $\theta$ ?

6.  $\forall z \in \mathbb{C}$ :

$$|e^z| = e^{\text{Re}(z)}$$

7. Consider a driven  $RC$  circuit (see below left). According to Kirchhoff's law the voltage drop across the resistor ( $IR$ , for current  $I$ ) plus the voltage drop across the capacitor ( $Q/C$ , for charge  $Q$ ) must equal the voltage applied by the a.c. generator ( $V_0 \cos(\omega t)$ ) (where the generator is operating at an angular frequency  $\omega$ ). Thus:

$$\frac{Q}{C} + R I = V_0 \cos(\omega t) \quad (16)$$

Since the the current flowing must accumulate as charge on the capacitor we have:

$$I = \frac{dQ}{dt} \quad (17)$$

Thus we have the differential equation:



$$\frac{Q}{C} + R \frac{dQ}{dt} = V_0 \cos(\omega t) \quad (18)$$

Using complex variable methods and guessing a solution of the form:

$$Q = Q_0 e^{i\omega t} \quad (19)$$

Determine the amplitude and phase of  $Q_0$  so you can express your final answer in real form:

$$Q = A \cos(\omega t + \phi) \quad (20)$$



8. Consider a driven  $RL$  circuit (see above right). According to Kirchhoff's law the voltage drop across the resistor ( $IR$ , for current  $I$ ) plus the voltage drop across the inductor ( $L dI/dt$ ) must equal the voltage applied by the a.c. generator ( $V_0 \cos(\omega t)$ ) (where the generator is operating at an angular frequency  $\omega$ ). Thus:

$$L \frac{dI}{dt} + R I = V_0 \cos(\omega t) \quad (21)$$

Using complex variable methods and guessing a solution of the form:

$$I = I_0 e^{i\omega t} \quad (22)$$

Determine the amplitude and phase of  $I_0$  so you can express your final answer in real form:

$$I = A \cos(\omega t + \phi) \quad (23)$$

9. Using the Euler relation:  $e^{i\theta} = \cos \theta + i \sin \theta$  show that:

$$\frac{d}{dt} e^{i\omega t} = i\omega e^{i\omega t}$$

where  $\omega$  is real and constant.

10. Since  $e^x e^y = e^{x+y}$ , it's clear that:

$$e^{i\theta} e^{i\phi} = e^{i(\theta+\phi)}$$

Expand both sides of this equation using the Euler relationship, and prove:

$$\sin(\theta + \phi) = \sin \theta \cos \phi + \cos \theta \sin \phi$$

and a similar relationship for cos.

11. Describe geometrically the set of points in the complex plane satisfying the following equations:

- (a)  $|z| = 2$
- (b)  $\text{Im}(z) = 2$
- (c)  $|z + 2i| = 2$
- (d)  $|z + 1| + |z - 1| = 8$

12. Calculate the sin of 1 radian directly with your calculator and compare that result to what you get if you sum the first 5 non-zero terms of the Taylor series for sin.

13. Evaluate  $\int e^{(a+ib)x} dx$  (where  $a, b \in \mathbb{R}$ ) and take real and imaginary parts to show:

$$\begin{aligned} \int e^{ax} \cos bx \, dx &= \frac{e^{ax}(a \cos bx + b \sin bx)}{a^2 + b^2} \\ \int e^{ax} \sin bx \, dx &= \frac{e^{ax}(a \sin bx - b \cos bx)}{a^2 + b^2} \end{aligned}$$

14. Show:  $\arcsin z = -i \ln \left( iz \pm \sqrt{1 - z^2} \right)$

15. Let  $z = e^{i\theta}$  ( $\theta \in \mathbb{R}$ ). Clearly,  $z^2 = e^{i2\theta}$ . Using  $z = \cos \theta + i \sin \theta$  directly calculate  $z^2$ . Use the result to show the double angle formulas:

$$\begin{aligned} \cos 2\theta &= \cos^2 \theta - \sin^2 \theta \\ \sin 2\theta &= 2 \cos \theta \sin \theta \end{aligned}$$

Consider  $z^3$  and prove the triple angle formulas.

16. If we consider the complex numbers  $z_1$  and  $z_2$  to be 2d vectors show that the dot product of these two vectors is:

$$\text{Re}(z_1 z_2^*) \quad \text{or} \quad \text{Re}(z_2 z_1^*)$$

Use this result to show:

$$\mathbf{A} \cdot \mathbf{B} = A_1 B_1 + A_2 B_2 = |\mathbf{A}| |\mathbf{B}| \cos \theta$$

17. Proceeding similar to the above problem, provide a formula for the cross product of two 2d vectors and then show:

$$|\mathbf{A} \times \mathbf{B}| = |\mathbf{A}| |\mathbf{B}| \sin \theta$$

18. If  $f = f_0 e^{i\omega t}$  and  $g = g_0 e^{i\omega t}$  where  $f_0$  and  $g_0$  are (complex) constants, then

$$\overline{\text{Re}(f)} \overline{\text{Re}(g)} = \frac{1}{2} \text{Re}(f^* g) = \frac{1}{2} \text{Re}(f_0^* g_0) \quad (24)$$

The overbar indicates the time average over the cycle period  $T$ :

$$\overline{w} = \frac{1}{T} \int_0^T w(t) dt \quad (25)$$